

IP Energizer[®] Instructions



IP Energizer® Instructions

Versions: IP Energizer Controller 1.31

PAE025 3v26

Introduction


In order to allow remote control of the IP Energizer® you will need to set up its Wi-Fi connection. If you do not need the IP Energizer remote control feature, you may simply connect the Energizer to the fence and turn it on and off via the front panel on/off switch.

Setting up the IP Energizer is not hard, but we all know that computer equipment can have issues. That is why we have staff ready to take your call and talk you through any issues.

Warning! Read the Energizer instruction manual and the safety information in it first!

Get Ready! You need:


1. The name of your home Wi-Fi network (also known as the SSID). On most Wi-Fi routers this is printed on the back, an example of which is shown below.




2. Your home Wi-Fi network password, if your Wi-Fi is password protected.
3. The IP Energizer placed within signal range of the Wi-Fi network.
4. Power supply for the IP Energizer via its 240V AC (power point) or 12V DC (battery).
5. A smart phone with an Android operating system for running the IP Energizer App
6. Your home Wi-Fi network connected to the Internet.
7. The IP Energizer App from Pakton (see below)

Get Set: Setting up the IP Energizer


1. Plug the IP Energizer into the power supply and turn it on. Be aware that the Energizer could start pulsing; if it does, turn it off using the 'Power' button on the front of the Energizer.
2. Wait for approximately 20 seconds until you see 'IP - 1' on the front of the IP Energizer. This means that the IP Energizer needs to be configured to connect to your Wi-Fi network.
3. Download the 'IP Energizer Controller' App from the [Google Play store](#) and install it on your Android phone or device.




4. Open the navigation drawer and tap settings. Press Configure IP Energizer.



Choose from the drop down box the SSID of your home Wi-Fi network and enter in the password if it has one. Next enter the IP Energizers serial number and finally choose a password. You will need this password again later when Adding a site.




5. Press submit, you will see the following screens as it configures the energizer with the details you have entered.




6. Look at the screen on the front of your IP Energizer. If you have entered in the Wi-Fi details correctly it should connect to your home Wi-Fi network and display 'IP-3'.
7. Congratulations – your IP Energizer is configured!

Go: Take control of your IP Energizer

1. To control the energizer from your android device you simply need to add a site. Go to the settings screen and press add site. Refer to part 4 under 'Get Set: Setting up the IP Energizer' above if you need a reminder as to how to get to the settings.
2. Enter a site name – we have chosen 'Horse Paddock', then enter the serial number of the IP Energizer, and the password you chose when you configured your IP Energizer. Then choose a threshold voltage – you will get a notification on your phone if the fence voltage falls below this. If you do not want this feature enabled choose 'disabled'. Press OK.



3. You can turn your IP Energizer on or off via this screen, or you can press 'Horse Paddock' and view a more detailed screen. Note that Cloud Connected simply indicates whether or not your phone is connected to the internet and has connected to our messaging servers. Or you can select the site to see more details and control it from there.




If you select the site – in our case ‘Horse Paddock’ you will transition to a more detailed screen. From here the Site Name you entered will appear at the top of the screen, followed by the status information of your IP Energizer, which includes:

- a. **Signal Strength:** This indicates how well your IP Energizer is connected to your Wi-Fi network; it is not the signal strength of your mobile phone.
- b. **Energizer Model:** This shows the model name of your IP Energizer.
- c. **IP Energizer State:** This shows ‘On’ when the IP Energizer is running and putting voltage down your fence. It states ‘Off’ if the IP Energizer is in standby mode waiting for you to turn it on.
- d. **Fence Voltage:** This shows the actual voltage on the Energizer fence terminals. This will update in real time.
- e. **Stored Joules:** This shows the stored energy used by the Energizer for each pulse. It will rise when the IP Energizer has to work harder under heavy fence loads.
- f. **Supply Voltage:** This shows voltage of the power supply that is being used to power your IP Energizer. This could be a battery’s voltage, or a power pack’s output voltage.
- g. **IP Energizer IP Address:** This is the IP address that has been allocated by your home Wi-Fi router to your IP Energizer.

8. Should you wish to add additional IP Energizers to your App, simply navigate back to the settings and add another Site.

9. You can edit the Sites settings at any point via the edit button or stop monitoring a site by deleting it using the trash can. To do this navigate to edit sites page.



Congratulations, you can now monitor and control your IP Energizer from anywhere in the world!

If you have not already done so, you can now connect the Energizer to the fence (as per the installation instructions in the Energizer manual), making sure that it remains in range of your home Wi-Fi.

Disclaimer: If you give the IP Energizer password and serial number to anyone else, they will also be able to turn your Energizer on and off. You can change the password at any time by defaulting your IP Energizer and reconfiguring it by following the steps under 'Get Set: Setting up the IP Energizer above.

Defaulting your IP Energizer

If you want to change the password of your IP Energizer, or if you need to reconfigure it to connect to a different Wi-Fi network, you will need to reset the IP Energizer to its factory default.

1. Ensure that the IP Energizer is in standby mode – (the screen is on, but it isn't pulsing).
2. Remove power from the IP Energizer (turn the 240Vac or 12V DC off at the source), wait until the screen is completely blank.
3. Turn power back on it back on and wait for the display to show characters. At this point press and hold the power button on the front of the IP Energizer – hold this for approximately 5 seconds and then release. You should notice that the screen shows '----'. Note that the energizer may start pulsing during this procedure.
4. Wait for about 20 seconds, the screen will then display 'IP-1' this means it has been defaulted.

IP Energizer LCD Display

After it is turned off, the Energizer will display the DC supply voltage for a few seconds and then show the IP Energizer status.

24.10

DC Supply Voltage

IP-1

The IP Energizer is waiting for you to set the Wi-Fi Network details

IP-2

Connecting to the saved Wi-Fi network name (SSID)

IP-3

Connected to you Wi-Fi network. This is the normal operating mode.

IP-4

Failed to connect to the Wi-Fi network – This may resolve itself

IP-5

Incorrect Wi-Fi password. Default the IP Energizer and reconfigure it again.

Extending Your Wi-Fi Range


You may find that the IP Energizer cannot connect to your home Wi-Fi because it is not within signal range. This issue can be overcome installing a Wi-Fi extender. Setup is typically simple and we have included the necessary steps that we used to configure the TP-Link Nano router (TL-WR702N).




1. Plug your Wi-Fi extender into USB power and switch it on, plug one end of the supplied Ethernet cable into the Wi-Fi extender, and the other into your computer



2. Open a web browser such as Google Chrome on your computer and go to <http://tplinklogin.net>
Enter User Name: **admin**
Enter Password: **admin**



3. Click quick setup and then next, choose Repeater and then click next again



4. Simply select your countries region and press 'Survey'
5. This should list all Wi-Fi access points that the Wi-Fi repeater can see, press connect for the access point that is your home Wi-Fi network
6. This should fill in all the necessary details required to connect to this network bar the password which you must fill in, this is the password that you use to connect to your current Wi-Fi network.
7. You will then be asked to reboot to save the settings. Click Reboot
8. Find a suitable location for your Wi-Fi extender; This needs to be close enough to your IP Energizer such that it can provide Wi-Fi signal to it, but also within Wi-Fi range of your current Wi-Fi network, plug it in and switch it on.
9. Your Wi-Fi signal range has now been extended and the IP Energizer should be able to connect to it

Using a portable 3G Portable Modem

If your IP Energizer is not within Wi-Fi range, you can use an off the shelf 3G or 4G portable modem such as the Huawei E5251. These are also known as pocket Wi-Fi. These devices use a carrier like Telstra's mobile network to gain Internet access and then create a Wi-Fi hotspot. You can use a contract or a prepaid SIM card with the network of your choice, but it must have data available on the plan. Please ensure there is a 3G or 4G signal from the network of your choice where the IP Energizer is to be located before considering this option. The IP Energizer only uses a very small amount of data, approximately 1MB per day.

www.pakton.com.au

Tel: +61 7 3888 3793

ST090 1V05